

# DWELLSCAPE™

## Care and Maintenance Instructions

Please contact your DwellScape dealer or [www.dwellscape.com](http://www.dwellscape.com) for Care and Maintenance Instructions.

Interior and Exterior mats with a breathable non-staining back should be used at all entrances to protect the flooring from dirt, grit, and moisture. Occasionally clean all mats to remove soil and grit. Temporarily use plywood to protect the product when moving heavy appliances across the floor. Non-staining felt pads at least 1" in diameter should be used under all furniture and chair pads underneath castor chairs.

### Daily Cleaning

Dust mop with a micro-fiber cloth, sweep, or vacuum. When dust mopping, always apply cleaner directly to microfiber cloth/pad never spraying the floor directly. Keep micro-fiber cloth clean by laundering when soil is noticeable. When vacuuming, be sure the beater bar is not hitting the floor.

Remove all spills and pet stains promptly not allowing topical moisture to remain on the floor. Use a recommended cleaner and microfiber cloth to rub the area clean.

**Recommended Daily Cleaner:** Bona-Hard Surface Floor Cleaner

### Periodic Cleaning

Occasionally damp mopping the floor with a well wrung mop is acceptable using a pH neutral cleaning solution. Never pour the solution/liquid directly on the floor. Damage caused from excessive wet mopping or flooding the floor, is not covered by the warranty.

DwellScape Waterproof LVT Flooring can be cleaned using a Steam Mop as long as the steam is delivered to a microfiber pad and not directly to the flooring itself. The Steam Mop must be set to the lowest temperature setting. When using a Steam Mop, sweep the long direction of The Product.

Damage caused from excessively wet maintenance or damaged caused by using non-recommended cleaning agents such as soap, polish, wax, detergents, and abrasive cleaners is not covered. See warranty for other exclusions.